



Dell Inspiron Mini 10 Battery Replacement

The battery is a source of power for the device.

Written By: Danielle Jarecki



INTRODUCTION

This guide will show you how to remove the battery. This might be a necessary step in replacing a faulty battery or as a safety precaution before working on any other elements of the device.

Step 1 — Battery



⚠ To prevent injury and loss of data, ensure the device is turned off.

- Slide the release latches out toward the edges to unlock the battery.

Step 2



- Remove the battery by pulling it up and out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 01:06:21 PM.